



## Transit Custom / New Transporter T7 SPRINGS

### Fitment Summary

#### Kit 28532-1

- 2WD DIESEL Panel Van SWB
- 2WD DIESEL Panel Van LWB

#### Kit 28532-2

- 2WD DIESEL Panel Van SWB (200kg constant load)
- 2WD DIESEL Panel Van LWB (200kg constant load)

#### Kit 28532-3

- 2WD DIESEL DCIV (Kombi) SWB (200kg constant load)
- 2WD DIESEL Tourneo SWB
- 4WD DIESEL Panel Van SWB (200kg constant load)
- 4WD DIESEL Panel Van LWB (200kg constant load)
- PHEV Panel Van SWB (200kg constant load)
- PHEV Panel Van LWB (200kg constant load)

#### Kit 28532-4

- 2WD DIESEL DCIV (Kombi) LWB (200kg constant load)
- 4WD DIESEL DCIV (Kombi) SWB (200kg constant load)
- 4WD DIESEL DCIV (Kombi) LWB (200kg constant load)
- 4WD DIESEL Tourneo
- PHEV DCIV (Kombi) SWB (200kg constant load)
- PHEV DCIV (Kombi) LWB (200kg constant load)
- PHEV Tourneo

#### Kit 28532-6

- 2WD DIESEL DCIV (Kombi) LWB
- 4WD DIESEL DCIV (Kombi) SWB
- 4WD DIESEL DCIV (Kombi) LWB
- PHEV DCIV (Kombi) SWB
- PHEV DCIV (Kombi) LWB

#### Kit 28532-5

- 2WD DIESEL DCIV (Kombi) SWB
- 4WD DIESEL Panel Van SWB
- 4WD DIESEL Panel Van LWB
- PHEV Panel Van SWB
- PHEV Panel Van LWB



LEIGHTON